



The grain mill grinder can mill the high volumes of grain to make flour and recipes incredibly easy. Owning your own grain mill will allow you to control exactly what goes into your bread, baking and other cooking and eating. In addition, grinding grains yourself means you will get more vitamins and minerals and their attendant health benefits.



LEJIEYIN 1000g Electric Stainless Steel High-speed Grain Grinder Mill

The fineness of the powder varies with the grinding time. You can control the grinding time or the number of grinding according to your needs.

Recommend grinding capacity one time : the material you gonna to grind one time must cover the long blade in the middle and no more than 2/3 of the tank.

Recommend use time: no more than 3 minutes. It takes 5-10 minutes to rest after every 3 minutes of work.

The grinder pulverizes materials through high-speed rotation and collision, which will generate heat to make the machine hot. This is a normal phenomenon and does not affect the normal use of the grinder. Please do not worry.

It is recommended to use a brush or towel to clean the cabin, and not to wash it with water directly. Water in the motor may cause safety hazards.

Tips :

The working principle is to crush the material into powder by the high speed rotation of the blades. The whole process takes place in an enclosed grinding chamber, which generates heat and causes the machine to heat up. Therefore, it is normal for the grinder to be slightly heated.

Specification:

Material:stainless steel

Capacity : 1000g

Voltage:110


Rated power: 2000W

Fineness:50-300Mesh

Rotation speed:25000r/min

Working time:5 minutes

Interval:5 - 10 minutes



How to exchange Carbon Brushes

Three steps to exchange carbon brush

Please find the carbon brush port on both side of the grinder.

Please rotate the nut counterclockwise with a slotted screwdriver till the little carbon brush loose enough to take out.

Put your new carbon brush into the port, and tighten the nut clockwise.

Blade replacement

To remove the blades,Use a screwdriver to hold down the middle screw, and Drive the wrench or sleeve counter-clockwise to loosen the locknut on the blade.

Tips:

Sometimes the grinder machine is not working,such as bad smell or smoke. Please don't worry and cut off the power. Check whether the CARBON BRUSHE are loosing ans Please Tighten the carbon brushes on both sides or Reducing the amount of grinding powder then try to start the